

BELT
HOLD DOWN 2167034
INSTALLATION INSTRUCTIONS

LOCATE HOLD DOWN
NO. 1 AS SHOWN AT
THE NEXT PARTITION
AWAY FROM THE "A"
FRAME LEG.

CUP PART UP

NO. 1

HOLD DOWN
NO. 1

BEND HOLD DOWN NO. 2
TO APPROX 85°
BEFORE INSTALLING

APPROX. PARALLEL
TO CASE TRAY

LOCATE HOLD DOWN
NO. 2 AT NEXT PARTITION
AS SHOWN.
REPEAT EVERY 10'.

NO. 2